ENGINE DRAWING / SCHEMA DE MOTEUR / DIAGRAMA DE MOTOR



(11) RATO issuing the warranty shall provide any documents that describe that manufacturer's warranty procedures or policies within five working days of request by the Air Resources Board.

(d) Emission Warranty Parts List.
(1) Fuel Metering System
(i) Carburetor and internal parts (and/or pressure regulator or fuel injection system).
(ii) Air/fuel ratio feedback and control system.
(iii) Cold start enrichment system.
(iv) Fuel Tank.
(2) Air Induction System
(i) Controlled hot air intake system.
(ii) Intake manifold.
(iii) Air filter.
(3) Ignition System
(i) Spark Plugs.
(ii) Magneto or electronic ignition system.
(iii) Spark advance/retard system.
(4) Exhaust Gas Recirculation (EGR) System
(i) EGR valve body, and carburetor spacer if applicable.
(ii) EGR rate feedback and control system.
(5) Air Injection System
(i) Air pump or pulse valve.
(ii) Valves affecting distribution of flow.
(iii) Distribution manifold.
(6) Catalyst or Thermal Reactor System
(i) Catalytic converter.
(ii) Thermal reactor.
(iii) Exhaust manifold.
(7) Particulate Controls
(i) Traps, filters, precipitators, and any other device used to capture particulate emissions.
(8) Miscellaneous Items Used in Above Systems
(i) Electronic controls.
(ii) Vacuum, temperature, and time sensitive valves and switches.
(iii) Hoses, belts, connectors, and assemblies.

RATO will furnish with each new engine/equipment written instructions for the maintenance and use of the engine/equipment by the owner.

ENGINE PARTS LIST / LISTE DES PIÈCES DU MOTEUR / LISTA DE PIEZAS DEL MOTOR

REF. NO.	PART NO.	DESCRIPTION	DESCRIPTION	DESCRIPCIÓN	QTY
	0070566	Engine 212 cc	Moteur 212 cc	Motor 212 cm^3	1
1	0070575	Cylinder head assembly	Ensemble de tete de cylindre	Conjunto de cabezal de cilindro	1
2	0069480	Gasket, cylinder head	Joint	Empaquetadura	1
3	0070573	Cover, cylinder head	Couvercle	Tapa	1
4	0070574	Gasket, cylinder head cover	Joint	Empaquetadura	1
5	0069482	Oil seal	Joint	Sello	1
6	0068061	Sensor, engine oil	Détecteur	Sensor	1
7	0068062	Cover, crankcase	Couvercle	Tapa	1
8	0068063	Gasket, crankcase	Joint	Empaquetadura	1
9	0068064	Oil dipstick	Jauge de niveau d'huile	Varilla de aceite	1
10	0069482	Oil seal	Joint	Sello	1
11	0068066	Bolt, valve adjusting	Boulon	Perno	2
12	0068065	Rocker valve	Soupape	Válvula	2
13	0068463	Engine recoil assembly	Moteur recule l'assemblée	Asamblea de retráctil de motor	1
14	0068464	Shroud	Enveloppe	Guardera	1
15	0070576	Carburetor	Carburateur	Carburador	1
16	0068071	Gasket, air cleaner	Joint	Empaquetadura	1
17	0068070	Gasket, carburetor	Joint	Empaquetadura	1
18	0068466	Air cleaner	Aérer le nettoyeur	Limpiador aéreo	1
19	0068074	Pulley, starter	Poulie de démarreur	Polea de arrancador	1
20	0068075	Fan, flywheel	Ventilateur	Ventilador	1
21	0070577	Flywheel	Volant-moteur	Volante	1
22	0068077	Coil, ignition	Bobine d'allumage	Bobina de encendido	1

PARTS DRAWING / SCHEMA DES PIÈCES / DIAGRAMA DE PIEZAS - PC0103008



PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS - PC0103008

REF. NO.	PART NO.	DESCRIPTION	DESCRIPTION	DESCRIPCIÓN	QTY
1	0069593	Frame	Cadre	Marco	1
2	0067131	Isolator left	Sectionneur gauche	Aislador izquierda	2
3	0067133	Isolator right	Sectionneur droite	Aislador derecho	2
4	0068303	Circuit Breaker 10 amp DC	Disjoncteurs 10 amp CC	Cortacircuitos 10 A CC	1
5	0068919	Circuit Breaker 13 amp dual	Disjoncteurs 13 amp double	Cortacircuitos 13 A doble	1
6	0067210	Ground terminal	Borne de mise à terre	Terminal, tierra	1
7	0068455	Decorative plate	Plaque décorative	Plato decorativo	1
8	0067126	Ignition switch	Interrupteur	Interruptor	1
9	0069851	Foot, rubber	Pied	Pie	4
10	0037762.01	Receptacle 5-20R	Prise 5-20R	Receptáculo 5-20R	2
11	0049365	Receptacle L14-30R	Prise L14-30R	Receptáculo L14-30R	1
12	0061990	Receptacle DC	Prise CC	Receptáculo CC	1
13	0067159	Rectifier	Redresseur	Rectificador	1
14	0068922	Panel, wired	Tableau complet câblé	Panel, cabeado completo	1
15	0068457	Assy, rotor/stator	Ensemble de rotor et stator	Conjunto, rotor y estator	1
16	0067139	Cover, end	Couvercle	Tapa	1
17	0067146	Connection board	Conseil de connexion	Tabla de conexión	1
18	0067140	Voltage regulator	La tension régulatrice	El regulador del voltaje	1
19	0067137	Brush module	Brosser le module	Cepille módulo	1
20	0067138	Support, bearing	Support, roulement	Soporte, Cojinete	1
21	0067143	Fuel cap	Capuchon	Tapa de combustible	1
22	0067145	Fuel filter	Filtre à carburant	Filtro de combustible	1
23	0068458	Fuel tank	Réservoir de carburant	Tanque de metal de combustible	1
24	0068300	Fuel gauge	Jauge de carburant	Indicador de combustible	1
25	0067157	Fuel shut-off	Alimenter d'arrêt	Abastezca de combustible válvula	1
26	0068459	Bracket, metal	Support	Soporte	1
27	0067155	Gasket, exhaust pipe	Joint	Empaquetadera	1
28	0070569	Muffler assembly	Ensemble de silencieux	Conjunto, silenciador	1

WARNING: To avoid possible personal injury or equipment damage, a registered electrician or an authorized service representative should perform installation and all service. Under no circumstances should an unqualified person attempt to wire into a utility circuit.

AVERTISSEMENT: Pour éviter toute blessure personnelle ou dommage à l'équipement, l'installation et tout entretien devralent être effectués par un électricien qualifié ou un préposé au service autorisé. En aucun cas, une personne non-qualifiée ne devrait essayer de faire le raccord au circuit principal.

ADVERTENCIA: Para evitar posibles lesiones físcas o daños materiales, es necesario que la instalación y todo el servicio sea realizado por un electricista matriculado o representatnte de servicio autorizado. Bajo ninguna circunstancia debe permitirse que una persona que no está capacitad trate de manipular cables dentro del circuito de servicio eléctrico.